

LX-100

1

RUN	TEACH	ADJ.	COLOR
/	TIMER	PRO	MODE/CANCEL
/	ON/SELECT	+ OFF/ENTER	-



2

		AUTO		
MODE	COLOR	AUTO	MODE	RUN

3

3997



2508

1400

4

MODE TEACH



ON



OFF

good

RUN



5

MODE

ADJ.

2868

